## Tenax

## **Briotop**

### NEUTRAL DETERGENT

Neutral detergent in practical spray bottle format. Ideal for cleaning all surfaces, the ideal ally for daily cleaning. It does not require rinsing and, thanks to its formulation, it leaves no streaks and dries quickly.

Before











FOR ALL SURFACES



LEAVES NO STREAKS



+ QUICK-DRYING

#### **Technical data:**

◆ Density at 25°C gr/cm3: 0,990

Standard colour: colourless

◆ Appearance: liquid



**Water based** 



#### Tools:

- Brush
- Cloth
- Sponge
- Fleece







Ceramic

#### How to apply it:

- Apply the product to a dry surface.
- Apply the product evenly.
- Do not expose to sunlight during application.
- Clean with a cloth.
- Rinse if necessary.

#### **Safety measures:**

Read the instructions in the technical and safety data sheet and the notes on the packaging before use. Close the container after use. For professional use only.

When a surface is treated for the first time, it is advisable to evaluate the effect or adhesion on a sample or hidden corner.

# Tenax



Apply the product to the surface



Leave on for a few moments



Clean the stain with cloth and/or sponge

Final result